Reccomended Spare/Replacement Parts for Your Machine

Customer Name	BTM Company
Job Number	FC-21-17825
Part Name	Hinge Plate

Feeding Concepts Inc.
317.773.2040
Parts@feedingconcepts.com

Please send all request for quotes and purchase orders to parts@feedingconcepts.com. All credit card transactions must be done through our Quote Valet system

FCI Part Number	Description	MPN	Quantity on Machine Shipped	Notes
Bowl/Hopper/Inline Parts				
E-0379	120V Coils for Base Drive	379	2	
SP-18	Steel Springs for 18" Base Drive Unit	SP18	11	(10) 3/8" - (1) 1/4"
#24	Rubber Isolation Feet for Base Drive	NA	4	
E-0185	120V Coil for Hopper Driver	185	1	
SP-HP	Springs for Hopper Driver	SPHP	3	(3) 1/8"
#27	Rubber Isolation Feet for Hopper Driver	27	4	
E-0383	120V Coil for Inline Driver	383	1	
SP-IN	Springs for Inline Driver	SPIN	5	(4) 1/8" - (1) 1/16"
Control Components and Sensors				

109	Rodix Controller for Bowl / Hopper / Inline	1210002000	3	120V
13	Keyence Fiber Unit	FU-R77TZ	1	
88	Keyence Main Unit Amplifier	FS-N41C	1	
10	Keyence Laser Sensor for Bowl Level	LR-ZH500CP	1	
86	2M Cable for Keyence Sensor	OP73864	2	
Other Components				
25	Machine Leveling Feet	M100-34-6	4	