These are the only parts that needed air to prevent parts from overlapping. For all other parts you should turn the air off.





