Reccomended Spare/Replacement Parts for Your Machine

Customer Name	BTM Company
Job Number	FC-22-19152
Part Name	Spacers

Feeding Concepts Inc.
317.773.2040
Parts@feedingconcepts.com

Please send all request for quotes and purchase orders to parts@feedingconcepts.com. All credit card transactions must be done through our Quote Valet system

FCI Part Number	Description	Quantity on Machine Shipped	Notes
Drive Unit Parts			
E-0379	E Series Vibratory Coil for Drive Unit	2	
SP-21-38	3/8" Springs for 21" Drive Unit	10	
#24	Rubber Isolation Feet for Drive Unit	4	
Hopper Parts			
E-0185	E Series Vibratory Coil for Hopper Driver	1	
SP-HP-18	1/8" Springs for Hopper Driver	4	
#27	Rubber Isolation Feet for Hopper Driver	4	
Controls and Sensors			
121-000-2000	Rodix FC-200 Feeder Cube for Bowl, Hopper	3	
Q4XTBLAF500Q8	Banner Q4X Series Sensor for Bowl Level	1	
RKT4-225/5M	Lumberg Cordset for Q4X	1	
Other			

M100-34-6	Machine Leveling Feet	4
FC-22-19152-IBF	Inside Line Blow Feed	1
FC-22-19152-OBF	Outside Line Blow Feed	1