# Reccomended Spare/Replacement Parts for Your Machine

| | |
|---|---|
| **Customer Name** | BTM Company |
| **Job Number** | FC-23-19984-(1-3) |
| **Part Name** | Insert |

Feeding Concepts Inc.
317.773.2040
Parts@feedingconcepts.com

***Please send all request for quotes and purchase orders to parts@feedingconcepts.com. All credit card transactions must be done through our Quote Valet system***

| FCI Part Number | Description | Quantity on Machine Shipped | Notes |
|---|---|---|---|
| **Drive Unit Parts** | | | |
| E-0379 | E Series Vibratory Coil for Drive Unit | 2 | |
| SP-15-38 | 3/8" Spring for 15" Drive Unit | 7 | |
| SP-15-14 | 1/4" Spring for 15" Drive Unit | 1 | |
| #24 | Rubber Isolation Feet for Drive Unit | 4 | |
| **Hopper Parts** | | | |
| E-0185 | E Series Vibratory Coil for Hopper Driver | 1 | |
| SP-HP-18 | 1/8" Springs for Hopper Driver | 4 | |
| #27 | Rubber Isolation Feet for Hopper Driver | 4 | |
| **Controls and Sensors** | | | |
| 121-000-2000 | Rodix FC-200 Feeder Cube for Bowl, Hopper, Inline | 3 | |
| FU-R77TZ | Keyence Thru-Beam Sensor | 1 | |
| OP73864 | Keyence Cordset for Amplifier | 1 | |

| | | |
|---|---|---|
| Q4XTBLAF500Q8 | Banner Q4X Series Sensor for Bowl Level | 1 |
| RKT4-225/5M | Lumberg Cordset for Q4X | 1 |
| **Other** | | |
| M100-34-6 | Machine Leveling Feet | 4 |
| FC-23-19984-SV | Square Venturi for Blow Feed | 1 |